





NOTICE DE MONTAGE




A		10x40	x67
B		M6x10x18	x28
C		M6x110	x27
D		M6x80	x1
E		M6x50	x1
F		M6x8x15x15	x1



G		7x60	x20
H		5,5x55	x2
J		D8x13	x4
K		D10x15	x8
L		D15x18	x34
			x2




A		10x40	x64
B		M6x10x18	x28


2





C		M6x110	x16
L		D15x18	x16




3





C		M6x110	x10
L		D15x18	x12

4a

MONTAGE DE L'ECHELLE A GAUCHE






C		M6x110	x1
D		M6x80	x1
E		M6x50	x1
F		M6x8x15x15	x1





A		10x40	x4
L		D15x18	x2

4b

MONTAGE DE L'ECHELLE A DROITE




A		10x40	x4
L		D15x18	x2

C		M6x110	x1
D		M6x80	x1
E		M6x50	x1
F		M6x8x15x15	x1

5a



MONTAGE DE L'ECHELLE A GAUCHE



G




7x60

x20

5b

MONTAGE DE L'ECHELLE A DROITE






G




7x60

x20





6a








56 VIS BOIS 4x30MM




VIS POUR FIXATION DU SOMMIER DEROULEUR

H		5,5x55	x2
J		D8x13	x4
K		D10x15	x8
L		D15x18	x2





6b



56 VIS BOIS 4x30MM



VIS POUR FIXATION DU SOMMIER DEROULEUR

H		5,5x55	x2
J		D8x13	x4
K		D10x15	x8
L		D15x18	x2